

NATIVE-MINI
MICROTCA CHASSIS WITH NAT-EMCH

DESIGNED BY N.A.T. GMBH



TECHNICAL REFERENCE MANUAL V1.1

HW REVISION 1.X




TABLE OF CONTENTS

| | |
|-------------------------------------------------------------------|-----------|
| 1. PREFACE | 5 |
| 1.1. Disclaimer | 5 |
| 1.2. About This Document | 6 |
| 2. INTRODUCTION | 7 |
| 2.1. Basic Functionality | 7 |
| 2.2. Applications | 8 |
| 2.3. Main Features | 9 |
| 3. QUICK START | 10 |
| 3.1. Unpacking | 10 |
| 3.2. Mechanical Requirements | 10 |
| 3.3. Voltage Requirements | 11 |
| 3.3.1. POWER SUPPLY | 11 |
| 3.3.2. HOT-SWAP | 11 |
| 4. HARDWARE | 12 |
| 4.1. Backplane | 13 |
| 4.2. NAT-eMCH – Component-, Connector-, and Switch-Location | 14 |
| 4.3. Front Panel, LEDs, and Connectors | 15 |
| 4.3.1. USB DEBUG CONNECTOR | 16 |
| 4.3.2. RJ45 CONNECTOR | 16 |
| 4.4. Cooling Unit, Fans, and Air-Filter | 17 |
| 5. OPERATION | 18 |
| 5.1.1. SYSTEM START-UP AND REDUNDANCY OPERATION | 18 |
| 5.1.2. AMC MODULE START-UP SEQUENCING | 18 |
| 5.1.3. LOCAL SHELF MANAGER | 18 |
| 6. CONFIGURATION | 20 |



| | | |
|-------------|-------------------------------------------------------------|-----------|
| 6.1. | COM-Settings | 20 |
| 6.2. | IPMI-Messages | 23 |
| 6.3. | Boot Manager | 24 |
| 6.4. | Updating the Firmware | 25 |
| 7. | MANAGEMENT INTERFACE | 27 |
| 7.1. | Software Structure | 27 |
| 7.2. | Communication between Host System and NAT-eMCH | 29 |
| 7.2.1. | REMOTE MANAGEMENT CONTROL PROTOCOL..... | 29 |
| 7.3. | Host Software Overview | 29 |
| 7.3.1. | NATVIEW | 29 |
| 7.4. | Known Restrictions | 31 |
| 8. | SPECIFICATIONS AND COMPLIANCES | 32 |
| 8.1. | Internal Reference Documentation | 32 |
| 8.2. | External Reference Documentation | 32 |
| 8.3. | Standards Compliance | 32 |
| 8.4. | Compliance to RoHS Directive | 32 |
| 8.5. | Compliance to WEEE Directive | 33 |
| 8.6. | Compliance to CE Directive | 33 |
| 8.7. | Compliance to REACH | 33 |
| 8.8. | Abbreviation List | 34 |
| 9. | DOCUMENT'S HISTORY | 35 |



LIST OF TABLES

| | |
|------------------------------------------------------|----|
| TABLE 1 – TECHNICAL DATA..... | 9 |
| TABLE 2 – AMC PORT ASSIGNMENT..... | 14 |
| TABLE 3 – LED FUNCTIONALITY | 15 |
| TABLE 4 – USB DEBUG CONNECTOR – PIN ASSIGNMENT | 16 |
| TABLE 5 – REMOTE CONTROL – PIN ASSIGNMENT | 16 |
| TABLE 6 – COM PORT SETTINGS | 20 |
| TABLE 7 – COMMANDS SUPPORTED BY CLI..... | 21 |
| TABLE 8 – SUPPORTED IPMI-COMMANDS | 23 |
| TABLE 9 – STANDARD INTERFACE CONFIGURATION | 25 |
| TABLE 10 – KNOWN RESTRICTIONS | 31 |
| TABLE 11 – ABBREVIATION LIST..... | 34 |
| TABLE 12 – DOCUMENT’S HISTORY | 35 |

LIST OF FIGURES

| | |
|-----------------------------------------------|----|
| FIGURE 1 – CHASSIS DESIGN | 7 |
| FIGURE 2 – BLOCK DIAGRAM..... | 12 |
| FIGURE 3 – BACKPLANE TOPOLOGY..... | 13 |
| FIGURE 4 – LOCATION DIAGRAM NAT-EMCH | 14 |
| FIGURE 5 – FRONT PANEL AND LEDS | 15 |
| FIGURE 6 – USB DEBUG CONNECTOR..... | 16 |
| FIGURE 7 – REMOTE CONTROL | 16 |
| FIGURE 8 – FIRMWARE UPDATE LOGIN | 25 |
| FIGURE 9 – FIRMWARE UPDATE UPLOAD..... | 26 |
| FIGURE 10 – FIRMWARE UPDATE SUCCESSFUL | 26 |
| FIGURE 11 – FIRMWARE UPDATE FAILURE..... | 26 |
| FIGURE 12 – SOFTWARE STRUCTURE OVERVIEW | 27 |
| FIGURE 13 – SOFTWARE STRUCTURE DETAILS | 28 |
| FIGURE 14 – NATVIEW..... | 30 |



1. PREFACE

1.1. Disclaimer

The following documentation, compiled by N.A.T. GmbH (henceforth called N.A.T.), represents the current status of the product's development. The documentation is updated on a regular basis. Any changes which might ensue, including those necessitated by updated specifications, are considered in the latest version of this documentation. N.A.T. is under no obligation to notify any person, organization, or institution of such changes or to make these changes public in any other way.

We must caution you, that this publication could include technical inaccuracies or typographical errors.

N.A.T. offers no warranty, either expressed or implied, for the contents of this documentation or for the product described therein, including but not limited to the warranties of merchantability or the fitness of the product for any specific purpose.

In no event will N.A.T. be liable for any loss of data or for errors in data utilization or processing resulting from the use of this product or the documentation. In particular, N.A.T. will not be responsible for any direct or indirect damages (including lost profits, lost savings, delays or interruptions in the flow of business activities, including but not limited to, special, incidental, consequential, or other similar damages) arising out of the use of or inability to use this product or the associated documentation, even if N.A.T. or any authorized N.A.T. representative has been advised of the possibility of such damages.

The use of registered names, trademarks, etc. in this publication does not imply, even in the absence of a specific statement, that such names are exempt from the relevant protective laws and regulations (patent laws, trade mark laws, etc.) and therefore free for general use. In no case does N.A.T. guarantee that the information given in this documentation is free of such third-party rights.

Neither this documentation nor any part thereof may be copied, translated, or reduced to any electronic medium or machine form without the prior written consent from N.A.T. GmbH.

This product (and the associated documentation) is governed by the N.A.T. General Conditions and Terms of Delivery and Payment.

Note:

The release of the Hardware Manual is related to a certain HW board revision given in the document title. For HW revisions earlier than the one given in the document title please contact N.A.T. for the corresponding older Hardware Manual release.



1.2. About This Document

This document is intended to give an overview on the **NATIVE-mini's** functional capabilities.

Preface

General information about this document

Introduction

Abstract on the **NATIVE-mini's** main functionality and application field

Quick Start

Important information and mandatory requirements to be considered before operating the **NATIVE-mini** for the first time

Hardware

Details on the **NATIVE-mini's** most important components and interfaces

Operation

Information on start-up sequence

Configuration

Adapting the **NATIVE-mini** to personal needs and updating the firmware of the **NAT-eMCH**

Management Interface

Information about the interaction of the **NAT-eMCH** and an external system controller

Specifications and Compliances

Detailed list of specifications, abbreviations, and datasheets of components referred to in this document, as well as standards, the **NATIVE-mini** complies to

Document's History

Revision record

Note:

It is assumed, that the **NATIVE-mini** is handled by qualified personnel only!




2. INTRODUCTION

The **NATIVE-mini** is a compact μ TCA chassis featuring two payload slots for single-wide, full- or mid-size AMC modules, and an embedded MCH (referred to as **NAT-eMCH** in this document), which enables the communication between the AMC modules and the monitoring of the system, including the power and cooling management.

The following figure shows the chassis design of the **NATIVE-mini**.

Figure 1 – Chassis Design



2.1. Basic Functionality

The **NAT-eMCH** provides via its 1GbE switch direct access to both AMCs and the system management via the 1GbE-Uplink at the chassis front. The 1GbE switch also allows the direct integration of the system components in an existing network infrastructure.

Unlike the **NAT-MCH**, the **NAT-eMCH** is restricted in its functional range. Nevertheless, it supports the typical hot-swap-management and its transition state machine (M0 to M6) for each AMC module.

In addition to that, the **NAT-eMCH** monitors and verifies local sensor data of the chassis and installed FRU devices, and supplies μ TCA power and cooling concepts by accessing the chassis integrated power supply and fan coolers. Remote administration can be done locally over the Command Line Interface served by the front USB port.

2.2. Applications

The **NATIVE-mini** aims for applications which are cost-sensitive and get along with only few AMCs, but on the other hand want to profit from the proven technological benefits that are offered by μ TCA (e.g. error detection and isolation, open system management and monitoring, etc.).

Due to the fact that the chassis is stackable or mountable in a 19" rack, the **NATIVE-mini** is multi-purpose and usable, e.g. for digital video and image editing, automation and machine control, electronic signal processing, security, and gateway.

2.3. Main Features

Table 1 – Technical Data

| Form Factor | |
|-----------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| | <ul style="list-style-type: none"> • 2-slot 1U chassis – 260mm x 43mm x 302mm (W x H x D) • designed for up to two single-wide, mid- or full-size AMCs • stackable or mountable in 19" racks |
| NAT-eMCH | |
| Processing Resources | <ul style="list-style-type: none"> • Atmel ATSAM4E16C Cortex-M4 processor @ 120 MHz • Main memory: 128 kByte embedded SRAM • FLASH PROM: 1024 kByte embedded FLASH ROM |
| Interfaces | <ul style="list-style-type: none"> • 1GbE switch for Fabric A • 1GbE-Uplink at front panel • local point-to-point connections at AMC ports 2-20 and TCLKA-D |
| System Management | <ul style="list-style-type: none"> • management and fault isolation for built-in power supply, fans, and AMCs |
| Software | <ul style="list-style-type: none"> • FreeRTOS 7.3.0 • Life-long free firmware update service • NATview-EASY included – compatible with V3.0 or higher only! • Configuration via web interface |
| Power Supply | |
| | <ul style="list-style-type: none"> • Integrated 150W AC Open Frame power supply (auto-range 100-240 VAC) • Power management on backplane • ON/OFF-switch • Simply replaceable |
| Cooling Units | |
| | <ul style="list-style-type: none"> • Integrated cooling units including air filter • Cooling power of 150W @ +55°C operating temperature • Fanspeed-controlled fans, controlled by temperature sensors and managed by NAT-eMCH • Supports side-to-side cooling • Simply replaceable |
| Front Panel | |
| | <ul style="list-style-type: none"> • 1x GbE interface via RJ45-connector • 1x console via Micro-USB • 2x green LEDs for status indication of each of the 2 AMC modules • 2x green/red LEDs for status indication of NAT-eMCH module |
| Compliance | |
| | <ul style="list-style-type: none"> • PICMG AMC.0 Rev. 2.0 • PICMG μTCA.0 • CE, RoHS • EN55032:2015, EN 55024:2010+A1:2015, EN IEC 62368-1:2020 + A11:2020 |
| Environmental | |
| Ambient Temperature | <ul style="list-style-type: none"> • -5°C to +45°C (long term) • -5°C to +55°C (short term) |
| Humidity | <ul style="list-style-type: none"> • 5% to 85%, non-condensing |



3. QUICK START

To ensure proper functioning of the **NATIVE-mini** during its usual lifetime, take the following precautions before handling the shelf.

3.1. Unpacking

Electrostatic discharge, incorrect board installation, and uninstallation can damage circuits or shorten their lifetime. Before touching integrated circuits ensure to take all required precautions for handling electrostatic devices.

Avoid touching gold contacts of the AMC-Edge-Connectors to ensure proper contact when inserting the modules into the **NATIVE-mini**.

Make sure that the chassis and its attachments are undamaged and complete according to delivery note.

3.2. Mechanical Requirements

Despite its compact design the **NATIVE-mini** is compliant to the open μ TCA standard MTCA.0 and therefore every standard-compliant, single full-size or mid-size AMC module can be integrated.

Before installing or uninstalling an AMC, read the Installation Guide and the User's Manual of the module.

Check all modules for steps that you have to take before turning on or off the power. After taking those steps, turn on or off the power if necessary.

Make sure the part to be installed/removed is hot-swap-capable, if you don't switch off the power.

Ensure that the module is connected to the **NATIVE-mini** with the connector completely inserted.

Install the system in an open rack whenever possible. If installation in an enclosed rack is unavoidable, ensure that the rack has adequate ventilation.

Maintain ambient airflow to ensure normal operation. If the airflow is blocked or restricted, or if the intake air is too warm, an over temperature condition can occur.

Ensure that cables from other equipment do not obstruct the airflow through the shelf.

Use filler panels which include an airflow baffle that extends to the backplane to cover all empty chassis slots. The filler panel prevents fan air from escaping out of the front of an open slot.

The **NATIVE-mini** is intended to be grounded. Ensure that the shelf ground terminals are connected to Protective Earth of the building.



3.3. Voltage Requirements

3.3.1. Power supply

The **NATIVE-mini** consumes 150W (determined by integrated power supply) at a voltage range from 100 to 240 VAC.

3.3.2. Hot-Swap

The **NATIVE-mini** supports hot-swapping, which means that an AMC module, which features hot-swap-capability as well, can be inserted or extracted during normal system operation without affecting other modules.

Make sure to follow the procedure **exactly** to prevent the AMC module or the system it is plugged into from damage!

Insertion of a hot-swap-capable module

- Ensure the module supports hot-swapping
- Ensure that the hot-swap-handle is in "unlock"-position (pulled out)
- Push the module carefully into the dedicated slot of the **NATIVE-mini** until it is completely inserted
- The blue HS-LED turns solid on
- With pushing the hot-swap-handle to "lock"-position, the HS-LED starts blinking and the IPMI-Controller of the backplane/carrier detects the board
- If the information provided by the module is valid, the **NATIVE-mini** enables payload power and the blue HS-LED turns off

Extraction of a hot-swap-capable module


- Pull the hot-swap-handle in "unlock"-position
- The blue HS-LED starts blinking
- The IPMI-Controller of the **NATIVE-mini** disables payload power
- The HS-LED turns solid on
- Pull the module carefully out of the **NATIVE-mini**



4. HARDWARE

The **NATIVE-mini** is made up of several functional blocks, which are described in the following paragraphs.


Figure 2 – Block Diagram



4.1. Backplane

The figure below shows the inner port assignment of the backplane and the way, how the **NAT-eMCH** is connected to it.

Figure 3 – Backplane Topology



To each of the AMC-Modules, the **NAT-eMCH** has radial connections including 1000Base-BX Ethernet (port 0 and 1), I²C-IPMB for management based on IPMI messages, and enable-/power switch signals for serving μ TCA hot-swap-capabilities.

AMC ports 0/1 are switched by the **NAT-eMCH**. AMC ports 2-11, FCKLA, and TCLKA-D are directly crossover connected between both of the AMC modules, which enables a high operational performance.




Table 2 – AMC Port Assignment

| AMC Port# | Assignment |
|-----------|--------------------------|
| 0 | Fabric 1/A – 1000Base-BX |
| 1 | Fabric 2/A – 1000Base-BX |
| 2 | SATA |
| 3 | SATA |
| 4-7 | Fat Pipe |
| 8-11 | Extended Fat Pipe |

Powers for payload (12V) and management (3.3V) for each installed AMC are circuit switched by a hot-swap-controller that remains on the backplane, and which is available via a further I²C-bus to the **NAT-eMCH**. A current sensor and the backplane FRU-EEPROM are also connected to that bus.

4.2. NAT-eMCH – Component-, Connector-, and Switch-Location

Figure 4 – Location Diagram NAT-eMCH



4.3. Front Panel, LEDs, and Connectors

The **NAT-eMCH** front panel features two status LEDs for the AMCs, and two LEDs (OK, FAIL) for the system's operation status; the behaviour is described in the table below.

Additionally, sockets for a RJ45 plug and a micro-USB cable are mounted.

Figure 5 – Front Panel and LEDs




Table 3 – LED Functionality

| LED | Color | Behaviour | Function |
|------------------------|-----------|------------|-----------------------------------------|
| LED AMC1 / LED AMC2 | green | Fast flash | Reading FRU information (M1) |
| | | Slow blink | Waiting for HS-Handle being closed (M1) |
| | | Solid ON | FRU operating state (M4) |
| | | Solid OFF | No module installed |
| LED OK | green/red | Fast flash | Test mode |
| | | Solid ON | Normal operating status |
| LED FAIL | green/red | Solid ON | Hard Fault |

4.3.1. USB Debug Connector

The **NATIVE-mini** features an USB debug interface towards the **NAT-eMCH**.

Figure 6 – USB Debug Connector




Table 4 – USB Debug Connector – Pin Assignment

| Pin # | Signal | Signal | Pin # |
|-------|--------|--------|-------|
| 1 | VCC | D- | 2 |
| 3 | D+ | nc | 3 |
| 5 | GND | | |

4.3.2. RJ45 Connector

A RJ45 connector offers an 1000Base-T interface for remote control.

Figure 7 – Remote Control




Table 5 – Remote Control – Pin Assignment

| Pin # | Signal | Signal | Pin # |
|-------|--------|--------|-------|
| 1 | MX0+ | MX0- | 2 |
| 3 | MX1+ | MX2+ | 4 |
| 5 | MX2- | MX1- | 6 |
| 7 | MX3+ | MX3- | 8 |

4.4. Cooling Unit, Fans, and Air-Filter

The **NATIVE-mini** is equipped with integrated air-filters and four fans, which are controlled by a temperature sensor and managed by the **NAT-eMCH**. Cold air is taken from the right side and led through the system. Thus, a cooling power of 150W at an operating temperature of +55°C (short term) is ensured.

For scalable applications, the chassis is stackable or mountable in 19" racks and supports side-to-side cooling. Fans and air-filters are simply replaceable.

5. OPERATION

5.1.1. System Start-up and Redundancy Operation

After power-up, the **NAT-eMCH** tries to read the backplane FRU information and locates the available power module and cooling unit before it starts scanning for installed AMC modules.

5.1.2. AMC Module Start-up Sequencing

For all AMC modules found in the system, the **NAT-eMCH** reads the FRU information and sensor data records. If power negotiation is successful, the power module is advised to power up the AMC modules either in the activation sequence defined in the 'Carrier Activation and Current descriptor' record of the backplane FRU device or - if the record is not found - according to the site number.

Any populated slot of the **NATIVE-mini** is represented by a green LED on the front panel.

5.1.3. Local Shelf Manager

The **NATIVE-mini's** local shelf manager provides management of the following resources within the μ TCA system:

- Sensor Event Log
- Temperature management and CU control

5.1.3.1. System Event Log

The **NAT-eMCH** provides a System Event Log that stores all events occurring in the μ TCA system. These events are kept in the **NAT-eMCH's** SRAM and are not stored into persistent memory.

Events can be read by an application using the IPMI message 'GET_SEL_ENTRY_REQ'.

Events are removed from the SEL on read. To remove single events from the SEL in this configuration, the IPMI message 'DELETE_SEL_ENTRY_REQ' has to be sent to the **NAT-eMCH**, by using 'CLEAR_SEL_REQ', the whole SEL is cleared.

Note: some events (e.g. temperature events) are handled by the local shelf manager.



5.1.3.2. Temperature Management

The local shelf manager receives temperature events from the following sources:

- Local temperature sensors on the **NAT-eMCH**
- Temperature sensors on the AMC modules
- Temperature sensors on Cooling Units and Power Modules

In case the **NAT-eMCH** receives a temperature event from a FRU, i.e. the temperature of a certain module has reached a critical level, it increases the fan speed of the Cooling Units to maximum and starts monitoring the temperature sensors of the respective FRU.

As soon as the temperature returns to normal level, the fan speed will be decreased to a level which is 10% higher than the level before the temperature event occurred. If the temperature is stable for a certain time, the fan speed will be reduced step by step.



6. CONFIGURATION

Compared to the **NAT-MCH**, the **NAT-eMCH** is limited in its functionality. The restrictions are listed below:

- The system is intended and tested to be used for offline mode, but it can also be used with limited RMCP functionality
 - Powering AMCs
 - Cooling AMCs based on temperature events
 - Fixed switching infrastructure
- RMCP support is limited to **NATview**, but third-party tools such as ipmitool can be used without warranty
 - Backplane FRU editor must not be used
- Since the NAT-eMCH does not support dynamic switching of Fat-Pipes, E-Keying functionality is not available
- MCH web server can only be used to update firmware, bootloader, and backplane FRU
- SEL and SDR does only include:
 - Temperature sensors
 - Hot swap handle
 - OEM sensors
 - (But all sensors can be displayed by CLI command show_sensorinfo <fru_id>)
- Maximum sensors per FRU device
 - AMC1-AMC2: 30

6.1. COM-Settings

The **NAT-eMCH** has a command line interface which allows users to initially set up configuration parameters as well as supplying low level diagnostic information. The CLI is available at the console port and telnet.

To establish a local connection to a host PC over USB, a serial terminal program is needed, e.g. Terra-Term, HTerm, Putty, etc. The configuration of the COM port settings is described in the following table.

Table 6 – COM Port Settings

| Parameter | Value |
|--------------|--------------------------------------|
| Baud rate | 115200 |
| Data | 8 bit |
| Parity | None |
| Stop | 1 bit |
| Flow Control | None |
| COM | Device's COM address defined by host |



If the terminal is opened, press `Enter` to see if the connection is established successfully. Typing `'help'` lists the available commands, `Enter` calls the previous command again.

Note: Depending on the used operating system, the FTDI-chip driver must be downloaded and installed manually (see chapter 8.2 External Reference Documentation). Installing the driver automatically by the windows update may take up to a few minutes.

The commands supported by the command line interface may vary with the firmware version. For a current list of available commands enter `'?'` at the command line prompt. Please note that some commands are intentionally not listed in the table because they are used for testing purpose only.

Table 7 – Commands supported by CLI

| Command | Parameter | Description |
|--------------------|-----------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| bi | | Board Information Prints the vital product information record (i.e. serial number, hardware revision, and release codes). |
| ip | | IP configuration Configures IP addresses, net mask, broadcast address, and gateway. |
| password | | Password Configuration Allows changing the password which is verified before starting a telnet session or accessing the webserver. A password length of not less than 8 to maximum 16 characters is required. The default password is set to <code>'nat'</code> . |
| reboot | | Reboot the NAT-eMCH |
| cmu_dbg | | Configure CM upper part debug |
| csif_dbg | | Configure CM/ShM interface debug |
| imsg_dbg | | Configure IPMI message debug |
| lshm_dbg | | Configure local ShM debug |
| rmcp_dbg | | Configure RMCP interface debug |
| sdrrep_dbg | | Configure SDR repository debug |
| sel_dbg | | Configure System Event Log debug |
| imsg_info | | IPMI message information Prints the implementation status of the supported IPMI messages on the Host (RMCP) interface and can be used to print a list of IPMI messages that are supported by the NAT-eMCH . |
| lshm_info | | Print local ShM information |
| idb_info | | Print IPMI data base information |
| sdrrep_info | | SDR repository information Prints an overview of the Sensor Data Repository of the NAT-eMCH . |



| Command | Parameter | Description |
|--------------------------|--------------|---------------------------------------------------------------------------------------------------------------------------------------------------|
| sel_info | | System Event Log information Prints the Sensor Event Log status and stored events in raw and decoded format. |
| session_info | | Session information Print status of currently active sessions. |
| show_ekey | | Show all activated connections |
| show_fru | | Show all FRUs |
| show_fruinfo | fru_id | FRU contents Shows the contents of a FRU device selected by <fru_id>. For valid FRU numbers please refer to MTCA R1.0 table 3-3. |
| show_pwrconf | | Power Configuration Displays the power channel assignment by the backplane FRU device |
| show_cu | | Show cooling unit |
| show_pm | | Power Module Status Shows the current power allocation status for all AMC modules and cooling units. |
| show_sensorinfo | fru_id | Shows the sensor values of the selected FRU |
| show_localsensors | | Show local sensor information of the chassis |
| version | | Print firmware version information |
| ni | | Print network configuration |
| ti | | Print task runtime information and memory usage |
| bl | | Starts the bootloader |
| ping | IP Address | Issue ICMP echo request This command supports several command line options. For more information on the command's usage, type 'ping -?' |
| diag | | Menu driven diagnostic tool This menu shall be used on N.A.T.'s explicit advice only |
| fan_ctl | | FAN control Command to get fan properties and speed level, and to set the fan speed level. |
| shutdown | <fru_id/all> | Successful shutdown of FRU or all AMCs |
| fru_start | <fru_id> | Successful start for FRU |



6.2. IPMI-Messages

The IPMI-Messages supported by the **NAT-eMCH** are listed in the following table.

Table 8 – Supported IPMI-Commands

| nfn | Command | Message |
|------|---------|---------------------------------------------|
| 0x06 | 0x01 | GET_DEVICE_ID_REQ |
| 0x06 | 0x02 | COLD_RESET_REQ |
| 0x06 | 0x03 | WARM_RESET_REQ |
| 0x06 | 0x04 | GET_SELF_TEST_RESULTS_REQ |
| 0x06 | 0x34 | SEND_MESSAGE_REQ |
| 0x06 | 0x38 | GET_CHANNEL_AUTHENTICATION_CAPABILITIES_REQ |
| 0x06 | 0x39 | GET_SESSION_CHALLENGE_REQ |
| 0x06 | 0x3a | ACTIVATE_SESSION_REQ |
| 0x06 | 0x3b | SET_SESSION_PRIVILEGE_LEVEL_REQ |
| 0x06 | 0x3c | CLOSE_SESSION_REQ |
| 0x06 | 0x3d | GET_SESSION_INFO_REQ |
| 0x06 | 0x3f | GET_AUTH_CODE_REQ |
| 0x06 | 0x40 | SET_CHANNEL_ACCESS_REQ |
| 0x06 | 0x41 | GET_CHANNEL_ACCESS_REQ |
| 0x06 | 0x42 | GET_CHANNEL_INFO_REQ |
| 0x06 | 0x43 | SET_USER_ACCESS_REQ |
| 0x06 | 0x44 | GET_USER_ACCESS_REQ |
| 0x06 | 0x45 | SET_USER_NAME_REQ |
| 0x06 | 0x46 | GET_USER_NAME_REQ |
| 0x06 | 0x47 | SET_USER_PASSWORD_REQ |
| 0x04 | 0x00 | SET_EVENT_RECEIVER_REQ |
| 0x04 | 0x01 | GET_EVENT_RECEIVER_REQ |
| 0x04 | 0x02 | PLATFORM_EVENT_REQ |
| 0x04 | 0x20 | GET_DEVICE_SDR_INFO_REQ |
| 0x04 | 0x21 | GET_DEVICE_SDR_REQ |
| 0x04 | 0x22 | RESERVE_DEVICE_SDR_REPOSITORY_REQ |
| 0x04 | 0x26 | SET_SENSOR_THRESHOLD_REQ |
| 0x04 | 0x27 | GET_SENSOR_THRESHOLD_REQ |
| 0x04 | 0x2d | GET_SENSOR_READING_REQ |
| 0x0a | 0x10 | GET_FRU_INVENTORY_AREA_INFO_REQ |
| 0x0a | 0x11 | READ_FRU_DATA_REQ |
| 0x0a | 0x12 | WRITE_FRU_DATA_REQ |
| 0x0a | 0x20 | GET_SDR_REPOSITORY_INFO_REQ |
| 0x0a | 0x22 | RESERVE_SDR_REPOSITORY_REQ |
| 0x0a | 0x23 | GET_SDR_REQ |
| 0x0a | 0x24 | ADD_SDR_REQ |
| 0x0a | 0x26 | DELETE_SDR_REQ |
| 0x0a | 0x27 | CLEAR_SDR_REPOSITORY_REQ |
| 0x0a | 0x2b | EXIT_SDR_REPOSITORY_UPDATE_MODE_REQ |
| 0x0a | 0x2c | RUN_INITIALIZATION_AGENT_REQ |
| 0x0a | 0x40 | GET_SEL_INFO_REQ |
| 0x0a | 0x42 | RESERVE_SEL_REQ |



| nfn | Command | Message |
|------|---------|--------------------------------------|
| 0x0a | 0x43 | GET_SEL_ENTRY_REQ |
| 0x0a | 0x44 | ADD_SEL_ENTRY_REQ |
| 0x0a | 0x46 | DELETE_SEL_ENTRY_REQ |
| 0x0a | 0x47 | CLEAR_SEL_REQ |
| 0x0a | 0x48 | GET_SEL_TIME_REQ |
| 0x0a | 0x49 | SET_SEL_TIME_REQ |
| 0x0c | 0x01 | SET_LAN_CONFIGURATION_PARAMETERS_REQ |
| 0x0c | 0x02 | GET_LAN_CONFIGURATION_PARAMETERS_REQ |
| 0x0c | 0x03 | SUSPEND_BMC_ARPS_REQ |
| 0x0c | 0x04 | GET_IP_UDP_RMCP_STATISTICS_REQ |
| 0x2c | 0x00 | GET_PICMG_PROPERTIES_REQ |
| 0x2c | 0x01 | : GET_ADDRESS_INFO_REQ |
| 0x2c | 0x04 | FRU_CONTROL_REQ |
| 0x2c | 0x05 | GET_FRU_LED_PROPERTIES_REQ |
| 0x2c | 0x06 | GET_LED_COLOR_CAPABILITIES_REQ |
| 0x2c | 0x07 | SET_FRU_LED_STATE_REQ |
| 0x2c | 0x08 | GET_FRU_LED_STATE_REQ |
| 0x2c | 0x0a | SET_FRU_ACTIVATION_POLICY_REQ |
| 0x2c | 0x0b | GET_FRU_ACTIVATION_POLICY_REQ |
| 0x2c | 0x0c | SET_FRU_ACTIVATION_REQ |
| 0x2c | 0x0d | GET_DEVICE_LOCATOR_RECORD_ID_REQ |
| 0x2c | 0x14 | GET_FAN_SPEED_PROPERTIES_REQ |
| 0x2c | 0x15 | SET_FAN_LEVEL_REQ |
| 0x2c | 0x16 | GET_FAN_LEVEL_REQ |
| 0x2c | 0x1c | SET_FAN_POLICY_REQ |
| 0x2c | 0x1d | GET_FAN_POLICY_REQ |
| 0x2c | 0x1e | FRU_CONTROL_CAPABILITIES_REQ |
| 0x2c | 0x1f | FRU_INVENTORY_DEVICE_LOCK_REQ |
| 0x2c | 0x20 | FRU_INVENTORY_DEVICE_WRITE_REQ |
| 0x2c | 0x19 | SET_AMC_PORT_STATE_REQ |
| 0x2c | 0x1a | GET_AMC_PORT_STATE_REQ |
| 0x2c | 0x23 | GET_LOCATION_INFO_REQ |
| 0x2c | 0x3e | <UNKNOWN_REQ> (netFn 0x2c cmd 0x3e) |
| 0x30 | 0x0d | NETFN_CONTR0_REQ |

6.3. Boot Manager

Note: Use this menu on N.A.T.'s explicit advice only!

The device contains a boot manager which normally executes either the firmware or the bootloader. By pressing 'x' to CLI at the boot process within half a second, the boot menu of the boot manager will be called, and the boot option (firmware, bootloader) can be chosen manually. Furthermore, the default configuration (e.g. IP settings, web password, etc.) can be restored.

6.4. Updating the Firmware

The **NAT-eMCH** serves a web based front end for easy upgrading the firmware in field. To use this utility, first establish an Ethernet link via the **NAT-eMCH** uplink port. If not changed, the standard interface configuration is as shown in the following table.

Table 9 – Standard Interface Configuration

| Parameter | Value |
|------------|---------------|
| IP Address | 192.168.1.138 |
| Netmask | 255.255.255.0 |
| Gateway | 0.0.0.0 |

First, the bootloader needs to be called by either typing ``bl'` to the command line interface or submitting ``http://192.168.1.138/'` to the web browser.

The index page is shown with a button ``call bootloader'`. By clicking this button, a software reset will be triggered and the system will boot into the bootloader.

Wait a few seconds and call ``http://192.168.1.138/'` again. The page should have changed slightly and will ask for a password (default ``nat'`).

Figure 8 – Firmware Update Login

The screenshot shows a web form for logging into the bootloader. It contains the following elements:

- A label "Password:" above a text input field.
- The text input field contains three dots (•••), indicating a password is entered.
- A "Submit" button located below the password field.
- A "Leave Bootloader" button located further down the page.

For leaving without any changes, use ``Leave Bootloader'`.

``Submit'` opens the following page:

Figure 9 – Firmware Update Upload




A valid N.A.T. firmware image with the file extension ``.srec`` has to be chosen. ``Upload`` flashes the image into the device memory.

Note: The upload process will take a few seconds, do not interrupt or close the browser while upgrading!

If successful, the following page is shown.


Figure 10 – Firmware Update Successful



Click on ``Reset MCU`` to trigger a software reset. The device should now boot into the new firmware.

Note: If an error occurs during the firmware upgrade (e.g. power or communication interrupted while transferring file), the device will boot into the bootloader again instead of loading the firmware. In this case the firmware upgrade can be started again.

Figure 11 – Firmware Update Failure



7. MANAGEMENT INTERFACE

For interfacing to a system controller, the **NAT-eMCH** is equipped with an Ethernet based management port, which resides on the front panel 1000 BaseT port. By the exchange of IPMI messages, an external system controller can communicate with the **NAT-eMCH**.


The IPMI messages are encapsulated in RMCP packets for transport via Ethernet. By this standard interface, the user has access to a broad range of open source and commercial tools to access and manage the **NAT-eMCH**.

The N.A.T. graphical system management JAVA application **NATview** utilizes this interface as well. Please make sure to use a compatible version of **NATview** (V3.0 or higher).

7.1. Software Structure

The following figure gives a basic overview about software structure on the **NAT-eMCH**.

Figure 12 – Software Structure Overview




The System Management Software (SMS) is running on a host system that communicates with the **NAT-eMCH** by RMCP via Ethernet. The **NAT-eMCH** itself implements base management controller (BMC) functionality and communicates over IPMI messages via I²C with hardware modules (e.g. Cooling Units, Power Modules, AMCs) that run hardware module specific software.



An example for a software implementation that uses a graphical JAVA application running on the host system is given below.

Figure 13 – Software Structure Details



The system management software is described more detailed in the following chapters.

The software on the **NAT-eMCH** can be divided up into two parts:

- A layer structured stack that implements the interfaces to external systems (host and hardware), and message handling
- Supporting modules to save data (IPMI data base, FRU inventory, SDR repository, SEL), and communication information (session management)

Note: the SEL on the **NAT-eMCH** is kept in memory but not stored into persistent memory.



7.2. Communication between Host System and NAT-eMCH

Communication between a host system and the **NAT-eMCH** is done via IPMI messages. To allow a flexible and common available transport of these IPMI messages, the **NAT-eMCH** offers an Ethernet based management interface.

7.2.1. Remote Management Control Protocol

Transport via Ethernet usually requires some high-level protocols to be used. The **NAT-eMCH** implements a Remote Management Control Protocol (see chapter 8.2 External Reference Documentation for details) interface, whereby the IPMI messages are embedded into the RMCP messages, which are sent using UDP via an Ethernet channel.

The RMCP fulfils all requirements to transfer IPMI messages via Ethernet:

- Presence echo mechanism (RMPC ping/pong messages)
- Message flow control via sequence numbers
- Support for multi-session
- Transfer of session header
- Support for authenticated access
- Per-message authentication disable
- User-level authentication disable

The **NAT-eMCH** supports access to the RMPC interface via its front Ethernet interface.

7.3. Host Software Overview


7.3.1. NATview

NATview is a graphical application that can be used to monitor and control an μ TCA system using IPMI messages. The application is written entirely in Java – it should therefore run on every operating system that is able to execute the Sun Java Runtime Environment (JRE).

Note: Make sure, to use a compatible version of **NATview** (V3.0 or higher)!



Figure 14 – NATview



7.3.1.1. Supported Java Releases

NATview requires Sun Java 1.6 or higher to guarantee the largest possible JRE installation basis on Window, Linux, and Mac OS X systems. For information about the Java version on the used system, enter '`java -version`' to a command prompt window.

For an appropriate copy of the Sun JRE, please refer to chapter 8.2 External Reference Documentation.

7.3.1.2. Installing and Running NATview

NATview is usually distributed as a zip archive via the N.A.T. FTP-Server (refer to chapter 8.1 Internal Reference Documentation). The following steps will install **NATview** on the system.

- Extract the content of the zip archives to an empty directory. This empty directory will be the root directory of the application.
- Start the application from within the root directory. Otherwise the application cannot find the board images in the subdirectory images.
- From the command line, type:

```
cd <root-directory>
java -jar natview.jar
```

7.3.1.3. Further Information

More detailed information can be found in the documentation that is accompanying the software.

7.4. Known Restrictions

Table 10 – Known Restrictions

| | |
|------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 0001 | ARP Request using a Windows PC may take longer than expected |
| 0002 | NATview support just in early beta state. It may cause errors with the NAT-eMCH . Also not all functions are supported yet (FRU-editor). Make sure, to use a compatible version of NATview (V3.0 or higher). |
| 0003 | Maximum number of sensors per FRU device is limited to 30 |
| 0004 | Only temperature sensors, device locator and OEM sensors are stored in the sensor data repository and thus visible for NATview. |
| 0005 | IPMItool operation is in beta state and not officially supported. Some commands may cause unexpected system behaviour. A list of supported commands can be found in Table 8 – Supported IPMI-Commands |



8. SPECIFICATIONS AND COMPLIANCES

8.1. Internal Reference Documentation

- **NAT-MCH** User's Manual
https://www.nateurope.com/manuals/nat_mch_man_usr.pdf
- **NATview**
ftp.nateurope.com – User: natmch – Password: natmch

8.2. External Reference Documentation

- Atmel ATSAM4E16C Microcontroller Datasheet, Rev. 11157H, 03/2016
- **FTDI-Driver**
<http://www.ftdichip.com/FTDrivers.htm>
- **Java**
<https://www.oracle.com/technetwork/java/index.html>
- **RMCP**
<http://www.dmtf.org/>

8.3. Standards Compliance

- PICMG AMC.0 Rev. 2.0
- PICMG μ TCA.0
- CE, RoHS
- EN55032:2015, EN 55024:2010+A1:2015, EN IEC 62368-1:2020 + A11:2020

8.4. Compliance to RoHS Directive

Directive 2011/65/EU of the European Parliament and of the Council of 8 June 2011 on the "Restriction of the use of certain Hazardous Substances in Electrical and Electronic Equipment" (RoHS) predicts that all electrical and electronic equipment being put on the European market after June 30th, 2006 must contain lead, mercury, hexavalent chromium, poly-brominated biphenyls (PBB) and poly-brominated diphenyl ethers (PBDE) and cadmium in maximum concentration values of 0.1% respective 0.01% by weight in homogenous materials only.

As these hazardous substances are currently used with semiconductors, plastics (i.e. semiconductor packages, connectors) and soldering tin any hardware product is affected by the RoHS directive if it does not belong to one of the groups of products exempted from the RoHS directive.



Although many of hardware products of N.A.T. are exempted from the RoHS directive it is a declared policy of N.A.T. to provide all products fully compliant to the RoHS directive as soon as possible. For this purpose since January 31st, 2005 N.A.T. is requesting RoHS compliant deliveries from its suppliers. Special attention and care has been paid to the production cycle, so that wherever and whenever possible RoHS components are used with N.A.T. hardware products already.

8.5. Compliance to WEEE Directive

Directive 2002/95/EC of the European Commission on "Waste Electrical and Electronic Equipment" (WEEE) predicts that every manufacturer of electrical and electronic equipment which is put on the European market has to contribute to the reuse, recycling and other forms of recovery of such waste so as to reduce disposal. Moreover this directive refers to the Directive 2002/95/EC of the European Commission on the "Restriction of the use of certain Hazardous Substances in Electrical and Electronic Equipment" (RoHS).

Having its main focus on private persons and households using such electrical and electronic equipment the directive also affects business-to-business relationships. The directive is quite restrictive on how such waste of private persons and households has to be handled by the supplier/manufacturer; however, it allows a greater flexibility in business-to-business relationships. This pays tribute to the fact with industrial use electrical and electronic products are commonly integrated into larger and more complex environments or systems that cannot easily be split up again when it comes to their disposal at the end of their life cycles.

As N.A.T. products are solely sold to industrial customers, by special arrangement at time of purchase the customer agreed to take the responsibility for a WEEE compliant disposal of the used N.A.T. product. Moreover, all N.A.T. products are marked according to the directive with a crossed out bin to indicate that these products within the European Community must not be disposed with regular waste.

If you have any questions on the policy of N.A.T. regarding the Directive 2011/65/EU of the European Parliament and of the Council of 8 June 2011 on the "Restriction of the use of certain Hazardous Substances in Electrical and Electronic Equipment" (RoHS) or the Directive 2002/95/EC of the European Commission on "Waste Electrical and Electronic Equipment" (WEEE) please contact N.A.T. by phone or e-mail.

8.6. Compliance to CE Directive

Compliance to the CE directive is declared. A 'CE' sign can be found on the PCB.

8.7. Compliance to REACH

The REACH EU regulation (Regulation (EC) No 1907/2006) is known to N.A.T. GmbH. N.A.T. did not receive information from their European suppliers of substances of very high concern of the ECHA candidate list. Article 7(2) of REACH is notable as no substances are intentionally being released by NAT products and as no hazardous substances are contained. Information remains in effect or will be otherwise stated immediately to our customers.

8.8. Abbreviation List

Table 11 – Abbreviation List

| Abbreviation | Description |
|---------------------|-----------------------------------------------------|
| AC | Alternating Current |
| AMC | Advanced Mezzanine Card |
| BIOS | Basic Input/Output System |
| BMC | Base Management Controller |
| CLI | Commend Line Interface |
| CPU | Central Processing Unit |
| COM | Communication Port |
| EEPROM | Electrically Erasable Programmable Read Only Memory |
| eMCH | Embedded MCH |
| FLASH | Non-Volatile Memory |
| FRU | Field Replaceable Unit |
| FTP | File Transfer Protocol |
| GbE | Gigabit Ethernet |
| GUI | Graphical User Interface |
| HS | Hot-Swap |
| I ² C | Inter-Integrated Circuit |
| IP | Internet Protocol |
| IPMB | Intelligent Platform Management Bus |
| IPMI | Intelligent Platform Management Interface |
| JRE | Java Runtime Environment |
| LAN | Local Area Network |
| μC/MCU | Microcontroller (Unit) |
| MCH | μTCA Carrier Hub |
| μTCA | Micro Telecommunications Computing Architecture |
| OS | Operating System |
| RMCP | Remote Management Control Protocol |
| SDR | Sensor Data Repository |
| SEL | System Event Log |
| SMS | System Management Software |
| SNMP | Simple Network Management Protocol |
| SRAM | Static Random Access Memory |
| UDP | User Datagram Protocol |
| VAC | Volt Alternating Current |
| TCKL | Telecom Clock |
| USB | Universal Serial Bus |



9. DOCUMENT'S HISTORY

Table 12 – Document's History

| Rev | Date | Description | Author |
|------------|-------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------|
| 1.0 | 2.07.2019 | <ul style="list-style-type: none"> initial release | se |
| | 13.01.2021 | <ul style="list-style-type: none"> Update title photo Minor changes | se |
| 1.1 | 18.03.2021 | <ul style="list-style-type: none"> Clarification on NAT-eMCH limitations compared to NAT-MCH (esp. chapter 6) Removed information regarding IPMItool usage due to beta state (see Table 10) Added note on NATview firmware version Added Table 8 | se |
| | 22.06.2021 | <ul style="list-style-type: none"> Minor changes in document layout and typo correction Updated Table 7 – Commands supported by CLI Specification and Compliances Update (chapter 8 and Table 1 – Technical Data) Deleted chapter "Product Safety" due to redundancy | se |

